



Retroflex RX2, RX3, Retroflex Comfort Crank

Centre Bolt Selection

The Retroflex is designed to fit exercise bikes, bicycles & Ebikes with a three or two piece, tapered or splined axle. This refers to the center axle of the bike. This is the axle that goes through the bicycle or exercise bike, and to which the existing cranks are fitted.

If you have a bolt or nut retaining your crank arm the Retroflex will fit.

Please select an option listed below—If you are unsure please email

unicam.paul@gmail.com

Typical Bicycle Axles



Square taper Axle Cartridge



Square taper Axle (Bolt & Nut)



Splined Axle

Common Axle Bolts



SRAM M15 x 1 pitch

A



FSA M15 x 1 & M18 x 1

B



M8 x 1 pitch

C



M12 x 1 pitch

D



M15 x 1 pitch

E



M10 x 1.25 pitch

F

E Bike Mid Drive Motors



Bosch



Yamaha



Bafang



M10 x 1 pitch

G



M12 x 1 pitch

H



M15 x 1 pitch

I